## LOADING INSTRUCTIONS



Load bike 1 (shown in black) front wheel first. Rotate front wheel so that it sits behind floor pin (shown in red) and rests against side panels Make sure rear wheel of bike one is against side panel Load bike 2 (shown in outline) rear wheel first making sure pedals do not cross

